



PENNBARRY

Please read and save these instructions. Read carefully before attempting to assemble, install, operate or maintain the product described. Protect yourself and others by observing all safety information. Failure to comply with instructions could result in personal injury and/or property damage! Retain instructions for future reference.

LC Dynafan Centrifugal Roof Exhauster



Receiving and Handling

PennBarry fans are carefully inspected before leaving the factory. When the unit is received, inspect the carton for any signs of tampering. Inspect the unit for any damage that may have occurred during transit and check for loose, missing or damaged parts. Mishandled units can void the warranty provisions. If units are damaged in transit, it is the responsibility of the receiver to make all claims against the carrier. PennBarry is not responsible for damages incurred during shipment.

Avoid severe jarring and/or dropping. Handle units with care to prevent damage to components or finishes. If the unit is scratched due to mishandling, the protective coating may be damaged. Incorrect lifting may damage the fan and void the warranty.

Storage

Long-term storage requires special attention. Store units on a level, solid surface, preferably indoors. If outside storage is necessary, protect the units against moisture and dirt by encasing the cartons in plastic or in some similar weatherproof material. Periodically inspect units and rotate wheels to spread bearing lubricant. Failure to rotate wheels results in reduced bearing life and may void the manufacturer's warranty. If the unit will be stored for an extended time, remove belts. Belts which remain under tension in a stationary position for extended periods are likely to have a reduced operating life.

Unpacking

Place the carton in an upright position and remove the staples or use a sharp (knife edge) tool to carefully cut or scribe the sealing tape on both sides at the top of the carton. Open carton flaps. Remove any cardboard and wooden filler pieces, as well as loose components or accessories shipped with the unit.

Carefully remove the unit from the carton. Inspect the unit for any damage that may have occurred during transit and check for loose, missing or damaged parts.

Installation

INSTALLING THE DAMPERS

When required, install dampers prior to mounting the unit on the curb or frame. Secure dampers to the inside of the curb without undue twisting, which may distort the damper frame. Damper frame must be reasonably level on all sides. Check for free operation. If dampers are motor operated type, ascertain that proper voltage is impressed on motor terminals.

POSITIONING AND RUNNING POWER LINES

Power is normally brought from within the building and placed inside one corner of the curb. Feed power line through the clearance hole provided in the damper if furnished, if not clearance hole is provided, remove a corner of the lower damper (with a shear cutter or other instrument), and in turn through the electrical conduit hole provided in the base of the exhauster (fed through rubber grommets on smaller units). If local codes require special electrical wire of unusually large size, then remove and discard the electrical conduit (or grommets) making sure to protect the wires from sharp edges.

INSTALLING THE FAN

For access to motor and drive assembly, simply remove or lift access hood and make necessary power connections to motor (through disconnect switch if required). Provide a generous amount of slack in power line between motor and disconnect switch to allow for motor deflections, and to permit movement or motor for belt tension adjustments.

ANCHORING OR SECURING THE UNIT

Whenever possible, anchor the fan by fastening through the vertical portion of the mounting flange. The type of fastener depends upon curb construction and using two fasteners per side constitutes adequate anchoring under normal conditions. If code or specification prescribes fastening through the top (horizontal portion) of the mounting flange, use neoprene or lead washers under the head of each fastener to prevent water leaks.

CAUTION Guy down large units installed in areas subject to high winds or unusual field conditions.

To complete the re-assembly of the unit secure hood to frame by replacing all spacers, washers and nuts exactly as they were found prior to removal. The unit is now ready for service. Apply power and check rotation as indicated by arrow in motor compartment. The rotation of all centrifugal ventilators is counterclockwise when viewing the unit from above the motor compartment.

CHECK LIST

The fan has been checked at the factory prior to shipment for mechanical noises. If installed properly, it will provide quiet ventilation. If noises should develop, check the suggestions below as a guide toward remedying the cause.

- Check rotating members for adequate clearance.
- Check proper belt tension and pulley alignment.
- Check installation and anchoring.
- Check fan bearings.

If your unit is exhausting over a hood which uses filters, clean the filters frequently. Dirty or clogged filters tend to increase static resistance and cause a reduction in air flow.


Start-Up and Operation

Carefully inspect the unit before start-up. All motor bearings should be properly lubricated and all fasteners should be securely tightened. Rotate blower wheels by hand to insure free movement. Make sure the inlets and approaches to the exhauster are clean and free from obstruction. To assure maximum air movement, adequate supply air must be available.

Rough shipping or handling may cause the wheel or propeller to move away from the venturi inlet. That condition can cause the fan to move less air. If that occurs, loosen set screws and adjust the impeller closer to the inlet. Retighten all hardware securely.

Check condition of belts and the amount of tension prior to start-up. When it becomes necessary to adjust belt tension, do not overtighten as bearing damage will occur. Recommended belt tension should permit deflection of 1/64" per inch of span of the belt on each side of the pulley centerline. Exercise extreme care when adjusting belts as not to misalign the pulleys. Any misalignment will cause a sharp reduction in belt life and produce squeaky, annoying noises. On units equipped with two or three groove pulleys, adjust all belts with equal tension.

Figure 1: Pulley Alignment



CAUTION Whenever belts are removed or installed, never force belts over pulleys without loosening motor first to relieve belt tension.

Before applying power to the motor, check the following:

- a. Check line voltage with motor nameplate.
- b. On single phase motors, set-up the terminal blocks in accordance with the nameplate instructions (or wiring diagram). The set up must match the line voltage.

- c. If the motor is three phase, group and connect the winding leads as shown on the wiring diagram. The line voltage must correspond with proper grouping of motor leads.
- d. On two speed motors, follow the wiring diagram explicitly or serious motor damage will occur.
- e. Activate the blower and allow it to operate.
- f. Carefully check the rotation of the wheel to insure operation in the proper direction.

CAUTION Incorrect rotation overloads motor severely and results in serious motor damage. To change rotation of three phase units simply interchange any two of the three line leads. On single phase units change the terminal block set-up following the wiring diagram.

- g. Check that bearing temperatures are not excessively hot.
- h. Check that all bolts and hangers are secure after one (1) hour of continuous operation.

NOTE: Take care to follow all local electrical, safety and building codes. Follow provisions of the National Electrical Code as well as the Occupational Safety and Health Act.

Always disconnect power source before working on the unit.

Guard and protect all moving parts.

All motors are checked prior to shipment. However, if motor defects should develop, prompt service can be obtained from the nearest authorized service station of the motor manufacturer under the warranty. Exchange, repair or replacement will be provided on a no charge basis if the motor is defective within the warranty period. Motor guarantee is void unless overload protection is provided in motor wiring circuit.

Maintenance

Do not attempt maintenance on a fan until the electrical supply has been completely disconnected. Lubrication is a primary maintenance responsibility. Check all bearings periodically. Inspect belts for tightness. If the fan is installed in a corrosive or dirty atmosphere, periodically clean the centrifugal wheel, inlet, motor housing and other moving parts.

FAN SHAFT LUBRICATION

Fan shaft bearing pillow blocks are furnished in either the pre-lubricated sealed-for-life type or the greasable type depending on what was ordered. The pre-lubricated type requires no servicing for 7 to 10 years of normal use and the greasable type are factory greased eliminating the need for greasing initially. Follow the lubricating schedule recommended by the factory. This practice should not supersede any safety considerations.

CAUTION Use low pressure grease guns only. High pressure guns tend to blow out or unseat bearing seals, leaving the bearing open to collect grime, dust and foreign particles.

LUBRICATION SCHEDULE

Always follow the bearing manufacturer's recommended lubrication schedule. If none is available use the following general schedule.

- a. Under average conditions where ambient temperatures do not exceed 120°F, lubrication is required 1 to 2 times a year.
- b. Under dirt laden atmosphere where there is a temperature range of 120°F to 150°F, lubrication is required from 3 to 6 times a year.
- c. Under extreme temperature conditions and extremely dirty atmospheres, lubrication should be scheduled at least once or twice a month.
- d. Belt driven units maximum temperature should not exceed 160°F. Direct driven models have temperature range stamped on motor.

Table 1: Recommended Lubricants

Manufacturer	Product	Temp. Range
BP	LG-#P-1	Below 32°F (0°C)
Gulf	Gulfcrown EP-1	
Imperial Oil	Unirex EP-1	
Shell	Alvania R-1	32°F to 150°F (0°C to 66°C)
BP	Energrease, MPMK11	
Gulf	Gulfcrown EP-2	
Imperial Oil	Unirex EP-2	
Shell	Alvania R-3	
Sun Oil	Sun Prestige 42	
Texaco	Regal AFB2	

MOTOR LUBRICATION

In general, standard motors are furnished with prelubricated, sealed-for-life ball bearings which require no lubrication for 7 to 10 years of normal service. Where motors have been ordered with greasable bearings, these bearings are factory lubricated and require no attention for one year under normal conditions. If grease relief fittings are provided, remove them when performing maintenance to allow grease to flow out. Whenever possible, apply grease while the motor is running. This practice should not supersede any safety considerations. **DO NOT OVER GREASE**, as most lubricants deteriorate motor windings, thereby reducing motor life and presenting a fire hazard.

Hidden Danger

In addition to the normal dangers of rotating machinery, fans present an additional hazard in their ability to suck in not only air, but loose material as well. Solid objects can pass through the fan and be discharged by the impeller as potentially dangerous projectiles. Therefore, screen intake to ductwork, whenever possible, to prevent the accidental entrance of solid objects. Never open access doors to a duct system with the fan running.

When starting the fan for the first time, completely inspect the ductwork and interior of the fan (with the power locked off), to make certain there is no foreign material which can be sucked into or blown through the ductwork.

Where the fan is accessible to untrained personnel or the general public, use maximum safety guards, even at the cost of some performance loss.

CAUTION *Unprotected fans located less than 7' above the floor also require guarding as specified in the Occupational Safety and Health Act (OSHA).*

Centrifugal fans may be connected directly to ductwork which will prevent contact with the internal moving parts, but when the inlet or outlet is exposed, install a suitable guard. PennBarry recommends the use of guards on all exposed non-ducted fans, ceiling and wall mounted.

Special Purpose Systems

Explosive, corrosive, high temperatures, etc. may require special construction, inspection and maintenance. It is necessary to observe the fan manufacturer's recommendations and limitations concerning the type of material to be handled by the fan and its application to special conditions.


Parts Replacements

If replacing parts, do so with properly selected components which duplicate the original parts correctly. Incorrectly sized shafts, belts, pulleys, centrifugal wheels, etc. can damage the fan.

PARTS LIST

1. Access Hood
2. Electrical Fan Motor
3. Centrifugal Fan Wheel
4. Anti-Vibration Mounts
5. Spun Inlet Venturi
6. Motor Support Plate
7. Conduit Hole
8. Fan Shaft and Bearings (Belt Drive only)
9. Belt and Pulley

Figure 2: Field Built Curbs



Troubleshooting Checklist

Symptom	Possible Cause(s)	Corrective Action
Excessive noise	<ol style="list-style-type: none"> 1. Defective or loose motor bearings 2. Ventilator base not securely anchored 3. Loose or unbalanced wheel/propeller 4. Misaligned pulleys or shaft 5. Loose or damaged wheel/propeller 6. Wheel running in wrong direction 	<ol style="list-style-type: none"> 1. Replace motor with same frame size, RPM, HP 2. Reset properly 3. Tighten screws, remove build-up, balance wheel/propeller 4. correct alignment 4. Replace wheel/propeller 6. Reverse direction
Fan inoperative	<ol style="list-style-type: none"> 1. Blown fuse or open circuit breaker 2. Loose or disconnected wiring 3. Defective motor 4. Broken belts 	<ol style="list-style-type: none"> 1. Replace fuses or circuit breaker 2. Shut off power and check wiring for proper connections 3. Repair or replace motor 4. Replace belts
Insufficient airflow	<ol style="list-style-type: none"> 1. Open access doors or loose sections of ducts 2. Clogged filters 3. Operation in wrong direction 4. Insufficient make-up air direction 	<ol style="list-style-type: none"> 1. Check for leakage 2. Clean filters 3. Correct rotation of wheel/propeller 4. Add make-up fan or louver opening
Water leaking into ductwork or collection of grease under fan	<ol style="list-style-type: none"> 1. Fan installed with slope in the wrong direction 2. Clogged drain spout 3. Cooling tube or motor dome top removed 4. Grease container full 	<ol style="list-style-type: none"> 1. Slope should be fitted in the direction of the drainage opening or grease collection box and drain spout 2. Clean drain spout 3. Install new cooling tube with gasket and dome top 4. Empty grease box
Motor overheating	<ol style="list-style-type: none"> 1. Belt slippage 2. Overvoltage or under voltage 3. Operation in wrong direction 4. Fan speed too high 5. Incorrect motor (service factor 1.0, low ambient temperature) 6. Blocked cooling tube or leaky gasket 7. Insufficient airflow to kitchen hood fan operating on low speed with kitchen in full operation 8. Undersized motor 	<ol style="list-style-type: none"> 1. Adjust tension or replace bad belts 2. Contact power supply company 3. Reverse direction of motor 4. Slow down fan by opening variable pitch pulley on motor shaft 5. Replace motor with correct open, NEMA service factors (1.15 or higher) with 40 degrees ambient 6. Remove blockage and seal cooling tube in place 7. Check airflow under hood and adjust kitchen equipment output 8. Check motor ratings with catalog speed and air capacity chart

Note: Care should be taken to follow all local electrical, safety and building codes. Provisions of the National Electric Code (NEC), as wells as the Occupational Safety and Health Act (OSHA) should be followed.

Limited Warranty

What Products Are Covered

PennBarry Fans and Ventilators (each, a "PennBarry Product")

One Year Limited Warranty For PennBarry Products

PennBarry warrants to the original commercial purchaser that the PennBarry Products will be free from defects in material and workmanship for a period of one (1) year from the date of shipment.

Exclusive Remedy

PennBarry will, at its option, repair or replace (without removal or installation) the affected components of any defective PennBarry Product; repair or replace (without removal or installation) the entire defective PennBarry Product; or refund the invoice price of the PennBarry Product. In all cases, a reasonable time period must be allowed for warranty repairs to be completed.

What You Must Do

In order to make a claim under these warranties:

1. You must be the original commercial purchaser of the PennBarry Product.
2. You must promptly notify us, within the warranty period, of any defect and provide us with any substantiation that we may reasonably request.
3. The PennBarry Product must have been installed and maintained in accordance with good industry practice and any specific PennBarry recommendations.

Exclusions

These warranties do not cover defects caused by:

1. Improper design or operation of the system into which the PennBarry Product is incorporated.
2. Improper installation.
3. Accident, abuse or misuse.
4. Unreasonable use (including any use for non-commercial purposes, failure to provide reasonable and necessary maintenance as specified by PennBarry, misapplication and operation in excess of stated performance characteristics).
5. Components not manufactured by PennBarry.

Limitations

1. In all cases, PennBarry reserves the right to fully satisfy its obligations under the Limited Warranties by refunding the invoice price of the defective PennBarry Product (or, if the PennBarry Product has been discontinued, of the most nearly comparable current product).
2. PennBarry reserves the right to furnish a substitute or replacement component or product in the event a PennBarry Product or any component of the product is discontinued or otherwise unavailable.
3. PennBarry's only obligation with respect to components not manufactured by PennBarry shall be to pass through the warranty made by the manufacturer of the defective component.

General

The foregoing warranties are exclusive and in lieu of all other warranties except that of title, whether written, oral or implied, in fact or in law (including any warranty of merchantability or fitness for a particular purpose).

PennBarry hereby disclaims any liability for special, punitive, indirect, incidental or consequential damages, including without limitation lost profits or revenues, loss of use of equipment, cost of capital, cost of substitute products, facilities or services, downtime, shutdown or slowdown costs.

The remedies of the original commercial purchaser set forth herein are exclusive and the liability of PennBarry with respect to the PennBarry Products, whether in contract, tort, warranty, strict liability or other legal theory shall not exceed the invoice price charged by PennBarry to its customer for the affected PennBarry Product at the time the claim is made.

Inquiries regarding these warranties should be sent to: PennBarry, 1401 North Plano Road, Richardson, TX 75081.