



UTILITY VENT SET FAN
 ELECTRICAL ACCESSORIES

Notes


- Input Power should be connected to Disconnect Switch (if ordered) otherwise can be mounted direct to Onboard Speed Controller or Motor.
- Mounted Electrical Accessories include Disconnect Switch, Onboard Speed Controller, and Pressure Transducer.
- Mounting Panel shall be located on right side of pedestal as viewed from drive side.




ARRANGEMENT-4 WITH ONBOARD SPEED CONTROLLER



ARRANGEMENT-4 WITHOUT ONBOARD SPEED CONTROLLER



ARRANGEMENT-10 WITH ONBOARD SPEED CONTROLLER



ARRANGEMENT-10 WITHOUT ONBOARD SPEED CONTROLLER